




RECOMMENDED HOURLY USAGE: 24 HOURS

ASSEMBLY INSTRUCTIONS



ERGO/KTAG/M

Do not tighten bolts fully until you have completed assembly.
Please note the fixing screws are located in their fixing points if not found in the parts bag.
"Should you require any assistance in assembling your goods please visit:
www.elizafurniture.co.uk/furniture and click on Customer Services"



WARNING:

- Do not stand on this chair. Do not use this chair as a step ladder.
- Use this product for seating only 1 person at a time.
- Do not use this chair unless all screws, bolts and knobs are securely fastened.
- Every 4 months inspect all screws, bolts and knobs to ensure they are fully tightened
- If parts are missing, incorrect or damaged stop using the chair immediately until repairs have been carried out by a competent person
- Failure to follow these warnings could result in serious injury.